



**KAYAKS2FISH**

# **ANCHOR TROLLEY INSTRUCTIONS**



STEP 1  
IDENTIFY THE WATERLINE WHEN THE KAYAK IS LOADED  
AND THE END USER IS ON THE KAYAK.

STEP 2  
MARK BOW, MID AND STERN SECTION FOR INSTALLATION  
OF PADEYES.

STEP 3  
DRILL MARKED PADEYE LOCATIONS WITH A SMALL DRILL  
BIT. THE DRILL BIT MUST BE A SMALLER DIAMETER THAN  
THE SELF TAPPING SCREWS PROVIDED.

STEP 4  
IN THE BOW SECTION, USING HAND TOOLS TO SCREW  
IN A PADEYE HORIZONTALLY.

STEP 5  
CONNECT ONE D-SHACKLE TO THE PADEYE.



STEP 6  
CONNECT A PULLEY TO THE D-SHACKLE.

STEP 7  
IN THE STERN SECTION, USING HAND TOOLS TO SCREW  
IN A PADEYE HORIZONTALLY.

STEP 8  
LOOP THE BUNGEE CORD THROUGH THE CONNECTION  
END OF THE PULLEY AND THE PADEYE.  
THE BUNGEE CORD IS USED AS A SHOCK ABSORBER.

STEP 9  
TIE A KNOT IN THE BUNGEE CORD.



STEP 10  
IN THE MIDDLE SECTION, USING HAND TOOLS  
TO SCREW IN A PADEYE DIAGONALLY.



STEP 11  
FEED THE ROPE SUPPLIED THROUGH THE PULLEY AT THE STERN, THROUGH THE MID SECTION PADEYE AND LOOP THROUGH THE BOW PULLEY, TEST THE LENGTH REQUIRED. *RECOMMENDED TO INSTALL WITH TENSION ON THE BUNGEE TO KEEP THE SYSTEM TIGHT.*

STEP 12  
FEED ONE RED BALL THROUGH THE ROPE END OF THE STERN MOUNT BEFORE TRYING TO CLIP THE REMAINING CLIP.

STEP 13  
FEED ONE RED BALL THROUGH THE ROPE END OF THE BOW MOUNT BEFORE TRYING TO THE STAINLESS RING. *THE RED BALLS ARE USED TO STOP ANCHOR TROLLEYS FROM GOING TOO FAR BEYOND BOW AND STERN PAD EYES.*

STEP 14  
CLIP THE ROPE BY ATTACHING THE RING TO THE CLIP.



STEP 15  
MARK OUT TWO HOLES WHERE THE ANCHOR TROLLEY GRIP WILL BE PLACED, TOWARDS THE BACK OF WHERE THE USER WOULD SIT AND BE ABLE TO REACH COMFORTABLY, ON THE SIDE ANCHOR TROLLEY SYSTEM WHICH HAS BEEN INSTALLED.

STEP 16:  
USE A 6MM DRILL BIT TO DRILL THE MARKED SPOTS, THEN CAREFULLY USE A 10MM BIT TO EXPAND THE HOLE.

STEP 17:  
INSERT WELLNUTS INTO THE HOLES DRILLED, THEY WILL BE VERY TIGHT. *RECOMMENDED TO USE A SMALL FLATHEAD SCREWDRIVER TO HELP FEED AND PUSH IN THE RUBBER FLANGED WELL NUT INTO THE HOLE.*

STEP 18  
LEAVE APPROX. 1 MM OF WELL NUT EXPOSED, LINE UP THE ANCHOR TROLLEY BRACKET, INSERT PROVIDED LONG SCREWS, TIGHTEN UNTIL THE RUBBER IS PUSHING ON BOTH SURFACES TO CREATE A WATERPROOF SEAL.