



KAYAKS2FISH

OUTRIGGER INSTRUCTIONS



STEP 1
PLACE THE CENTRE BAR INTO THE ALLOCATED
SLOT OR BRACKET.

STEP 2
MARK THE CENTRE POLE WITH A SMALL DOT WHERE
THE CENTRE SCREW WOULD SIT WITH THE PLATE
FOR THE STANDARD INSTALLATION OR
THE BRACKET FOR NON K2F KAYAKS.

STEP 3
REMOVE THE CENTRE POLE FROM THE KAYAK.

STEP 4
DRILL A HOLE THROUGH THE CENTRE POLE
AT THE MARKED POINT



Please Note: If you are planning on installing a motor block you may need to shift the centre pole further to the left or right to ensure enough room for the motor.



STEP 5
PLACE CENTRE POLE BACK ON THE KAYAK.

STEP 6
INSERT THE KEYED S BARS INTO THE CENTRE POLE .

STEP 7
ADJUST THE OUTRIGGER TO THE CORRECT POSITION.

STEP 8
MARK A DOT THROUGH YOUR PREVIOUS HOLE ONTO
THE S POLES.

STEP 9
REMOVE THE S POLES AND DRILL THROUGH THEM IN
THE MARKED SPOT ALL THE WAY THROUGH.

STEP 10
PLACE THE S POLES BACK INTO THE CENTRE BAR AND
SCREW DOWN THE MOUNTING PLATES.

Please Note: How far you have the outriggers out from the kayak is a personal preference. The further out the outriggers are from the kayak the more stable it is. The closer they are to the kayak the more compact the kayak will be.



STEP 11
SCREW THE LONG SCREW DOWN THROUGH
THE POLES INTO THE CENTRE BRASS INSERT.

STEP 12
ATTACH THE PODS ON EITHER END AND
SCREW ON WITH INCLUDED SCREWS.

