KAYAKS2FISH

INFLATABLE OUTRIGGER INSTRUCTIONS

Step 1

Connect the two poles together

Step 2

Place the poles in place into the divot at the back of the kayak behind the seat

Step 3

Place the metal plates over the bar in line with the brass inserts

Step 4

Screw down the metal plates with the included butterfly screws

Step 5

Slide on the outrigger pod

Step 6

Add end clip

Step 7

Inflate